

Using the BMW Z3 Seat Spacer Gauges

1. Remove the nuts and bolts from the seat
2. Position the 10mm spacer under the front of the seat
3. Position the seat and secure the rear bolts

Be careful as the front of the seat is not secured while you are using the gauges

4. Carefully sit in the seat and adjust the back rest
5. Carefully slide the seat fore and aft until you are comfortable
6. Carefully get out of the car and remove the rear bolts
7. Add one of the 5mm wedges to the 10mm gauge and goto 3 above
8. Repeat the test until you have tested all the heights
9. When you have tested all the heights, remove the gauges and secure the seat with the original nuts and bolts
10. Return the gauges

Be aware that you may have disturbed the wiring to the seat belt holder. If you have, you will need to reset the airbag light.

Please return the gauges using the label and stamp provided. If you were careful opening the jiffy bag, you should be able to reuse it.

Contents:

2x 10mm gauges

6x 5mm gauges

Set of instructions

Return address label

Stamps to use to return package